



GEMINI
COATINGS

PRODUCT DATA SHEET

RESTORE A DECK™

DESCRIPTION

Restore-A-Deck™ Cleaner is Step One of a TWO STEP state-of-the-art system for restoring your exterior wood to like new condition! Restore-A-Deck™ Cleaner offers a proprietary blend of detergents that are uniquely superior for wood restoration. Restore-A-Deck™ is biodegradable and 100% bleach-free.

PRODUCT NUMBER	DESCRIPTION CONTINUED	DIRECTIONS FOR USE
<p>895</p>	<p>Restore A Deck is a specifically designed two-part system that is best used to clean and prep a wood deck prior to resealing it. The Restore A Deck cleaner system consists of a wood cleaner (Step 1) that will remove dirt, grime, mold, mildew, and grayed wood fibers. Step 2 of RAD Cleaner is a wood brightener that corrects the pH of the wood and brightens it up prior to applying a wood stain or sealer.</p> <p>PRECAUTIONS: Avoid prolonged contact with skin or eyes. Always use protective eyewear. If product comes in contact with your eyes, flush with fresh water. Prolonged skin exposure may cause irritation. Always wash hands with soap and water after handling either the cleaner or brightener. If cleaner is ingested, milk or diluted vinegar is to be given. If brightener is ingested, several glasses of water are to be given. Do Not Induce Vomiting, Seek Medical Attention Right Away. Keep out of reach of children.</p>	<p>STEP ONE MIXING FORMULA: Mix 6 ounces of Restore-A-Deck™ Cleaner per gallon for light cleaning, 8 ounces per gallon for medium cleaning or 10 ounces for heavy cleaning. Mix Restore-A-Deck™ Cleaner in warm water until all crystals have dissolved.</p> <p>After mixing, apply with a pump-up garden sprayer. Do not allow the cleaner to dry on the wood. Keep the surface wet with solution for fifteen minutes. Older, untreated wood or surfaces with failing stain or sealer may require some scrubbing. The unique action of Restore-A-Deck™ detergent blend will attack mold and dirt causing it to rise to the surface for simple rinsing. If you are using a pressure washer to remove the cleaner, scrubbing is not necessary. Always use less than 1000 psi.</p> <p>If using a garden hose to rinse, scrubbing is recommended. If after rinsing the wood still has gray areas, re-apply to those areas, scrub and re-rinse. After rinsing, apply Step Two Brightener for a perfect pH balance and brightening.</p> <p>STEP TWO MIXING FORMULA: Stir one cup of brightener per gallon of warm water until all crystals have dissolved (or simply pour entire container into 5 gallons of warm water). Apply directly to wood surface with a pump-up garden sprayer. After you have treated the entire surface, rinse with a garden hose. It is not necessary to scrub or use a pressure washer. Before you apply the brightener, be certain all remaining gray areas on the wood have been removed with the cleaner.</p>
<p>DESCRIPTION</p> <p>The American Cedar Association and many true wood restoration professionals recommend that all wood be cleaned and brightened before applying a sealer.</p> <p>Products available at home centers are merely blends of bleach and soap. Using an inferior cleaner on your wood surface can cause damage to the wood fibers and reduce the life of your deck, fence, siding or shingles. This is why Restore-A-Deck™ is sold as a kit that includes a blue-labeled brightener for pH balance.</p> <p>Restore-A-Deck™ was designed by wood restoration professionals. PressurePros, Inc. uses the exact formulation and procedure on hundreds of decks, fences, driveways and houses per year. Use Step One to clean your home's exterior, lawn furniture or concrete. We know you will love your results.</p>		

Revised February 4, 2016

The following supersedes any provision contained in the forms, letters and papers of your company. This product is designed and intended for professional application only. All products should be thoroughly tested under application conditions prior to use. The information contained herein is believed to be reliable. **HOWEVER, GEMINI MAKES NO WARRANTY CONCERNING THIS PRODUCT, WHETHER EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.** UNDER NO CIRCUMSTANCES SHALL GEMINI BE LIABLE FOR SPECIAL, INCIDENTAL, CONSEQUENTIAL, OR ANY OTHER DAMAGES FROM ALLEGED NEGLIGENCE, BREACH OF WARRANTY, STRICT LIABILITY, OR ANY OTHER LEGAL THEORY, ARISING OUT OF THE USE OR HANDLING OF THIS PRODUCT. THE SOLE REMEDY OF THE BUYER AND THE SOLE LIABILITY OF GEMINI FOR ANY CLAIMS SHALL BE LIMITED TO THE BUYER'S PURCHASE PRICE OF THE PRODUCT WHICH IS THE SUBJECT OF THE CLAIM OR THE AMOUNT ACTUALLY PAID FOR SUCH PRODUCT, WHICHEVER IS LESS. TECHNICAL ADVICE FURNISHED BY GEMINI SHALL NOT CONSTITUTE AN EXPRESS WARRANTY, WHICH IS EXPRESSLY DISCLAIMED. ALL TECHNICAL ADVICE GIVEN IS ACCEPTED AT THE RISK OF THE BUYER. **CAUTION: DANGER! FLAMMABLE! VAPORS MAY CAUSE FLASH FIRE. VAPOR HARMFUL. HARMFUL OR FATAL IF SWALLOWED. INJURIOUS TO EYES. KEEP OUT OF THE REACH OF CHILDREN!** BEFORE using this product it is essential that the "Material Safety Data Sheet" describing the product as well as the "Product Label" be reviewed. If your company does not have such information or has any questions, contact the manufacturer.